MICRON µ **Plast** s.r.l.

Modena 01/08/2017

SUCTION LINE

MicAir ®

NEW SUCTION INTAKE RANGE
## THICKNESS 2 mm. FOR 10 cm WALLS.
## "MA-PAR-2000"

To meet the most demanding requirements in the suction intake field we have drawn on over thirty years of experience to design and manufacture a new conception, ultra-flat suction intake.


By MICRONPLAST srl
Via Bussi 70 41126 Modena ITALY

INSTALLING THE INTAKE ON 10 cm PLASTERBOARD WALLS

"MA- PAR-2000"

1/2	**INSTALLING MADE EASY FOR WALLS IN PLASTER-BOARD WITH FIXING ON MINIMUM 74 mm FRAME**		**CUTTING DIAM. 90 HOUSING FOR SUCTION INTAKE BOX ON PLASTERBOARD**		
3/4	**INSERT THE "MA-PA-SCA-90" BOX WITH THE TUBING IN THE HOLE MADE PREVIOUSLY**		**FIX THE "MA-PA-SCA-90" BOX WITH 4 SCREWS**		
5/6	**SHAVE THE WALL AND FINISH THE SURFACE**		**REMOVE THE PLASTER PROTECTION COVER AND FREE THE ELECTRIC WIRES. CHECK THAT THE "O-RING" SEAL IS POSITIONED CORRECTLY IN ITS HOUSING**		
5/6	**CONNECT THE ELECTRIC WIRES TO THE SPECIAL TERMINALS ON THE "MA PAR-2000" INTAKE**		**FIX THE INTAKE TO THE "MA-PA-SCA-90" BOX FIXED PREVIOUSLY**		

INSTALLING ON BRICK WALLS

1/2	**MAKE A BREAK IN THE BRICKWORK FOR THE "MA-PA-SCA-90" BOX HOUSING TO BE WALLED**		**POSITION THE BOX TO BE WALLED, WITH THE PLASTER PROTECTION COVER SUPPLIED, FLUSH WITH THE FINISHED PLASTER**	
3/4	**FIX THE BOX, WITH THE PLASTIC PROTECTION COVER, CONSIDERING IT HAS TO REMAIN FLUSH WITH THE FINISHED PLASTER**		**FINISH WITH PLASTER, SCRAPING UNTIL FLUSH WITH THE BOX**	
5/6	**REMOVE PLASTER COVER AND FREE THE ELECTRIC WIRES. CHECK THAT THE "O-RING" SEAL IS POSITIONED CORRECTLY IN ITS HOUSING**		**CONNECT THE ELECTRIC WIRES TO THE SPECIAL TERMINALS ON THE REAR OF THE "MA PAR-2000" MOUTH**	
7	**INSERT THE "MA PAR-2000" MOUTH INTO THE BOX HOUSING, THEN ADJUST THE MOUTH AND PLACE FLUSH WITH THE WALL AND LASTLY TIGHTEN THE SCREWS**			